

The followings are procedures to install the print driver and add a printer.

1. Installation

The installation procedures are as follow:

1. Download the image file(.dmg) from our web site.
2. Double click the image file(.dmg)
3. Double click the installer in the mounted volume.
4. Enter the Administrator's name and password.
5. A dialog box presenting the License Agreement is displayed.

Click "Agree" if you agree with the License Agreement to continue the installation procedures.

If you select "Disagree" in the License Agreement, the program will not install any files.

6. Click the "Install" button.

2. Add printer on Mac OS X 10.3

1. Start "Print Setup Utility", click "Printers" on the menu bar, and then select "Add Printer".
(Print Setup Utility is available in the /Applications/Utilities folder.)

2. Select the protocol for connecting to the printer.

2-1. For AppleTalk

- (1) Select "AppleTalk" and then the printer zone.
- (2) From the printer list, select the printer to use.
- (3) Click "Printer Model" and then select "Auto Select".
- (4) Click "Add".

** A "Multiple printer files were found" message may appear.

Select the PPD file for the printer and click "Add".

2-2. For IP

- (1) Select "IP Printing".
- (2) Select "LPD/LPR" for "Printer Type".
** "IPP (Internet Printing Protocol)" and "Socket/HP JetDirect" cannot be used.
- (3) Enter the IP address of the printer in "LPR Printer Address".
- (4) Click "Printer Model" and then select the PPD file for the printer from "FX".
- (5) Click "Add".

2-3. For USB

- (1) Select "USB".
- (2) From the printer list, select the printer to use.
- (3) Click "Printer Model" and then select the PPD file for the printer from "FX".
- (4) Click "Add".

3. Select the added printer from the "Printer List" window, click "Printers" on the menu bar, and then select "Show Info".

4. Select "Installable Options" and then specify the options installed on the printer.

5. After the option is specified, click "Apply Changes".

Notes on adding printers:

- Connection Protocol

"Windows Printing", "Rendezvous", and "Open Directory" cannot be used.

3. Add printer on Mac OS X 10.4

1. Start "Print Setup Utility", click "Printers" on the menu bar, and then select "Add Printer".
(Print Setup Utility is available in the /Applications/Utilities folder.)

2. Operations depend on the type of protocol for connecting to printer as follows.

2-1. For AppleTalk / USB / Bonjour

(1) Select "Default Browser".

(2) From "Printer Name", select the printer to use.

(3) Click "Print Using" and select the PPD file for the model from "FX".

* For AppleTalk, the PPD file for the model is selected automatically in "Print Using".

From the list displayed, select the PPD file for the printer and click "Add".

(4) Click "Add".

2-2. For IP

(1) Select "IP Printer".

(2) From "Protocol", select "LPD(Line Printer Daemon)".

* "Internet Printing Protocol-IPP" or "HP jet Direct-Socket" cannot be used.

(3) Enter the IP address of the printer in "Address".

(4) Click "Print Using" and then select the PPD file for the printer from "FX".

(5) Click "Add".

(For AppleTalk, the following operations are not required.)

3. "Installable Options" is displayed. Specify the option installed on the printer.

4. After the option is specified, click "Continue".